



## Resetting the Fire-Alarm

UT Department of Theatre • 206 McClung Tower • Knoxville, TN 37996

During normal operations, contact the House Manager, Stage Manager, or Production Manager.

— O T H E R W I S E —

Daytime  
UT Electrics Shop  
865.974.2505

Evenings & Weekends  
UT Police  
865.974.3114

### NOTES FOR LOCATING AN ALARM

---

1. Note the number of alarm sources indicated on the display (i.e. Fire=# or Trouble=#)
2. Press the appropriate “Alarm Ack” button to display each alarm source one at a time.
3. If the alarm(s) was(were) triggered by a smoke/duct detector, check the location(s) indicated to verify that there is no fire; otherwise evacuate.

### ZONE BYPASS ENABLE/DISABLE:

---

1. If bypassing the alarm, call UT Central Alarm (4-0808) BEFORE going any further.
2. Insert the fire key.
3. Gently press the grey zone button for the area to be bypassed. (Indicator will light/turn off and enunciator will beep)
4. Wait for the system to disable/enable all of the detectors in this zone (Trouble=# counts up or down)
5. Repeat to disable/enable an additional zone or press “Trouble Ack” under the Trouble indicator to finish.
6. Remove the fire key.

### SILENCING AN ALARM: (Note: To silence the alarm, whatever triggered the alarm must be stopped or the affected detectors must be bypassed.)

---

1. Insert the fire key and press “Alarm Silence”.
  2. Wait for the alarm to reset.
  3. Remove the fire key.
-